

PELCO/TEECO ADAPTER INSTALLATION INSTRUCTIONS

Rev. 01/06/04

Polara's adapter is designed to fit Pelco and Teeco cups and frames. However, the tops of the surfaces where their two threaded button mounting holes are located tend to vary in height and sometimes do not support our adapter directly under our mounting holes. If the nylon spacers supplied fit between Polara's spacer and the top surface of the mounting holes, use them to fill the gap. Otherwise discard them.

When tightening the two screws, only tighten them until the lock washer is compressed. Overtightening can cause the inner wall of the adapter to crack. If it cracks the spacer is still usable and still very strong, but try to avoid causing the inner wall to crack.

Should you have any questions, please call at:
Polara Engineering 888-340-4872

